



LISTENING COMPREHENSION

NUMBERS

ATIS: 0-6-1-1; 2-2; 2-0-0; 4; 1-6-0; 2-4-0; 1-5, 1 thousand; 1 thousand 4 hundred; 3 thousand; +9; +7; 1-0-2-7.

Frequencies: 1-6; 1-2-1; 1 // 1-2-0; 7-5-5 // 1-2-1; 8 // 1-2-6; 9-5-0 // 4-85; 1-1-8; 1-5; 1-1-8; 4-5; 4-85; 1-1-8; 1-5; 18-15 // 1-2-4; 1-5; 1-65; 1-2-4; 5; 9-2-3; 1-2-4; 1-5; 24-15.

Taxi ...: 6-0; 1-0; 7; 6-0; 1-3-0; 12; 1-1-8-6; 18-6; 6-0 // 5-6; 1; 3-4; 2; 2; 1-0 // 3; 2; 3-4 // 7-9-8; 1-2-0; 1-3; 1-0 // 3-4-0; 5; 2-5.

Altitude ...: 2-6; 1-8-0 // 6-0; 2-5-0 // 3-7-0-7 // 3-8; 2-9-0 // 7-9-8; 1 thousand, 9 thousand // 1-7 thousand // 7 thousand // a mile and a half // 1 thousand 7 hundred; 3-7-1-2; 1-1-8-6.

